Amplifiers and sensor modules

Main data for Memory relays

Туре	Symbol	Description	Connection (1)	Weight kg	Order code
Complete with sub-base PZU-		With priority reset signal and visula indication With manual override	Ø4 mm Swivel push-in	0,19	PLM-A12 *
Without sub-ba For sub-base PZ		With priority reset signal and visulal indication With manual override		0,14	PLM-A10 *
1011	x 🛦 🔭	Without manual override		0,13	PLM-B10

Main data for Amplifier relays

Туре	Symbol	Description		Connection (1)	Weight	Order code
Complete with sub-base PZU-	B12	This relay	is used to amplify	ø Ø4 mm	0,18	PRD-A12 *
	P P P P P P P P P P P P P P P P P P P	the low pressure signal provided by a fluidic proximity sensor to a useable level With manual override		Swivel push-in		
Vithout sub-ba or sub-base PZI		This relay is used to amplify the low pressure signal provided by a fluidic proximity sensor to a useable level With manual override			0,13	PRD-A10 *

Main data for Sensor relays

Type Symbol	Description	Connection (1)	Weight kg	Order code
Complete with sub-base PZU-A12 PR A12 *	This relay is used to provious to a bleed sensor and to generate a pneumatic signal equal to its supply pressure	de a supply Swivel push-in	Ø4 mm	0,07
Without sub-base For sub-base PZU-A12 or PZU-C12	This relay is used to provide a supply to a bleed sensor and to generate a pneumatic signal equal to its supply pressure		0,03	PRF-A10 *

* ATEX version available Order code example : **PLM-A12-EX**

(1) For other type of connections contact your Technical Sales Department

